

# CABLE FAST MARKERS

#### Description


Cable marking is essential and helpful when installing cables. This will ensure the right patch cords and cables are connected correctly to avoid unnecessary connection errors.

The snap-on markers have numbers from 0-9 and letters from A-Z for applying easily and securely on both ends cables and patch cords. This provides positive identification and allows error-free installation of your critical systems. The marks are permanent and chemical resistant, and suitable for Ø3mm and Ø2mm cables and patch cords.




- Snap-on marks for post-termination application
- Secured grip
- Easy and Convenient
- Chemical resistant
- White body, black mark: 0-9, A-Z
- Suitable for Ø3mm and Ø2mm cables

## **Specifications**



## **Ordering Information**



Wire diameter Mark 2=Ø2.0mm, 3=Ø3.0mm From 0-9, A-Z



#### **Applications**

Cable marking/identifying





Pacific Interconnections • www.pacificinterco.com • 425-2779527